



## Teknatool **nova** Cole Jaw / Planscheiben Segmente DT6040 | DT6006 | DTJSCOLE

### Assembly instruction:

Mount the cole jaws with the delivered M6 x 20 mm countersunk head screws and use one set of regular jaws for the assembly.

Typically, 50 mm jaws are used, but you can use all other sizes of jaws from the Teknatool **nova** range, which fit on G3 and SuperNova 2 chucks.

The cole jaws do not have a fixed sequential arrangement like the clamping jaws do.

### Montagehinweis:

Fixieren Sie die Planscheiben Segmente mit den mitgelieferten M6 x 20 mm Senkkopfschrauben und nutzen Sie einen Satz Spannzangen zur Montage.

Üblicherweise werden die Spannzangen 50 mm verwendet, Sie können aber auch alle anderen Teknatool **nova** Spannzangen nutzen, die auf G3 und SuperNova 2 Futter passen.

Eine Reihenfolge wie bei den Spannzangen selbst, muss bei den Planscheibensegmenten nicht beachtet werden.

